



s100N

1.09m Maritime Satellite TV
Antenna System

Installation & Operation User Guide

Serial number of the product

--

This serial number will be required for all troubleshooting or service inquiries.



© 2022 Intellian Technologies, Inc. All rights reserved. Intellian and the Intellian logo are trademarks of Intellian Technologies, Inc., registered in the U.S. and other countries. The s100N is a trademark of Intellian Technologies, Inc. Intellian may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Intellian, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property. All other logos, trademarks, and registered trademarks are the property of their respective owners. Information in this document is subject to change without notice. Every effort has been made to ensure that the information in this manual is accurate. Intellian is not responsible for printing or clerical errors.

Disclaimer

The information in this user manual is subject to change without prior notice throughout the product life cycle. The printed version of the user manual is periodically updated, so this copy may contain inaccuracies or omissions compared to the most recent product information. The most up-to-date information is available on our website at www.intelliantech.com.

Table of Contents

Chapter 1. Precautions	7
1.1 Warnings, Cautions, and Notes	7
1.2 General Precautions	7
Chapter 2. Certifications	8
Chapter 3. Introduction	11
3.1 Introduction of s100N	11
3.2 Features of s100N	12
Chapter 4. Planning Installation	13
4.1 Selection of Installation Site	13
4.1.1 Minimize Satellite Blockage	13
4.1.2 Avoid RF Interference	14
4.2 System Package	15
4.2.1 Above Deck Unit (ADU)	15
4.2.2 Antenna Control Unit (ACU)	16
4.2.3 Multi Switch Module (MSM)	16
4.2.4 Packing List	17
4.3 System Cables (Customer Supplied)	18
4.3.1 RF Cables (Customer Supplied)	18
4.3.2 Gyrocompass Cable (Customer Furnished)	18
4.4 Unpacking System Package	19
Chapter 5. Installing Above Deck Unit (ADU)	21
5.1 Antenna Dimensions	21
5.2 Antenna Mounting Hole Pattern	22
5.3 Designing Mast (Example Only)	23
5.4 Routing RF Cable on Mast (Example Only)	25
5.5 Removing Antenna from Wooden Pallet	26
5.6 Moving Antenna Above Mast	27
5.7 Mounting Antenna on Mast	28
5.8 Connecting RF Cable to Antenna	29
Chapter 6. Installing Below Deck Unit	31
6.1 Selection of BDU Installation Site	31
6.2 ACU Dimensions	31
6.3 MSM Dimensions	32
6.4 Mounting ACU/MSM	33
6.5 System Configurations	34
6.5.1 Single Antenna System Configuration	34
6.5.2 Dual Antenna System Configuration (Optional)	35
6.6 BDU Cable Connection	36
6.6.1 ACU Back Panel Connectors	36
6.6.2 MSM Back Panel Connectors	36

6.6.3 ACU Connector Pinout Guide	37
6.6.4 MSM Connector Pinout Guide	40
6.6.5 Connecting Power to ACU	41
6.6.6 Connecting ACU to ADU	41
6.6.7 Connecting ACU to Ship's Gyrocompass	42
6.6.8 Connecting RF Cables (RF1-4) to the Multi-Switch Module	43
6.7 ACU to PC Communication Setup	45
6.7.1 TCP/IP Connection	45
6.7.2 USB Connection	46
6.7.3 Wi-Fi Connection	47

Chapter 7. Operating Install Wizard	48
7.1 Turning On System	48
7.2 Accessing AptusNTV	48
7.3 Starting Install Wizard	49

Chapter 8. Operating ACU	54
8.1 Introduction	54
8.1.1 ACU Front Panel View	54
8.1.2 ACU Display Menu	55
8.2 Startup	56
8.3 Satellite Information	57
8.4 Interface Information	59
8.5 Antenna Information	60
8.6 Diagnosis	61
8.7 USB Function	63
8.7.1 Log Download	64
8.7.2 Firmware Upload	65
8.7.3 Backup to USB	66
8.7.4 Restore From USB	67

Chapter 9. Using AptusNTV	68
9.1 Introduction	68
9.2 Accessing AptusNTV for ACU	68
9.3 Main Page (Page Login)	69
9.4 Top Menus	70
9.5 Account Menu	71
9.5.1 Account	72
9.5.2 User Management	73
9.5.3 System Information	74
9.5.4 Support	75
9.6 Dashboard	76
9.6.1 How to Add & Remove Panels (Dashboard Setting)	76
9.6.2 How to Use Shortcut Settings	78
9.7 Setup	79
9.7.1 Ship	79
9.7.2 Antenna Setting	81
9.7.3 Satellite Set	84

9.7.4 Network	85
9.7.5 Wi-Fi	86
9.7.6 Mediator (Optional)	87
9.8 System Tools	88
9.8.1 ACU Upgrade	88
9.8.2 Firmware Upgrade	90
9.8.3 Library	92
9.8.4 Satellite Preset	93
9.8.5 Backup & Restore	94
9.8.6 Reset	95
9.8.7 Logs	96
9.8.8 Diagnostic	97
9.9 Install Wizard	98
Chapter 10. Specification	99
10.1 Technical Specification	99
10.2 Environmental Specification	101
Chapter 11. Warranty	102
Chapter 12. Appendix	103
12.1 Appendix A. Tightening Torque Specification	103
12.2 Appendix B. Important notice of waterproofing connector	104
12.2.1 Introduction	104
12.2.2 Outline of taping	104
12.2.3 Procedure	104

List of Figures

Chapter 4. Planning Installation	13
Figure 1: Elevation Limit of Obstacles	13
Figure 2: Potential RF Interference	14
Figure 3: Radome and Pedestal	15
Figure 4: Front Panel of ACU	16
Figure 5: Back Panel of ACU	16
Figure 6: Front Panel of MSM	16
Figure 7: Back Panel of MSM	16
Chapter 5. Installing Above Deck Unit (ADU)	21
Figure 8: Antenna Dimensions	21
Figure 9: Antenna Mounting Hole Template	22
Figure 10: Recommended Size of Mast	24
Figure 11: Routing Cable Through Outside of Mast	25
Figure 12: Placing Antenna on Mast	27
Figure 13: Installing Sequence of Bolts	28
Figure 14: Installing Bolts for Antenna-Mast Assembly	28
Chapter 6. Installing Below Deck Unit	31
Figure 15: ACU Dimensions	31
Figure 16: MSM Dimensions	32
Figure 17: 19-inch Rack Mount ACU (MSM)	33
Figure 18: Multi-Switch Connection Configuration	34
Figure 19: Dual Antenna System with Multi-Switch Connection Configuration	35
Figure 20: ACU Back Panel Connectors	36
Figure 21: MSM Back Panel Connectors	36
Figure 22: Connecting Power to ACU	41
Figure 23: ACU to Antenna Cable Connection	41
Figure 24: ACU to Ship's Gyrocompass Cable Connection	42
Figure 25: NMEA 0183 Gyrocompass Cable Connection	42
Figure 26: Multi-Switch Module Connection	43
Figure 27: Front Panel Management LAN Port Connection	45
Figure 28: Front Panel USB Port Connection	46
Figure 29: Rear Panel Wi-Fi Dongle Connection	47
Chapter 7. Operating Install Wizard	48
Figure 30: Front Panel Management LAN Port Connection	48
Chapter 8. Operating ACU	54
Figure 31: ACU Front Panel View	54

Chapter 1. Precautions

1.1 Warnings, Cautions, and Notes

WARNING, CAUTION, and NOTE statements are used throughout this manual to emphasize important and critical information. You must read these statements to help ensure safety and to prevent product damage. The statements are defined below.

	WARNING WARNING indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.
	CAUTION CAUTION indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury. It may also be used to alert users about unsafe practices.
	NOTE A NOTE statement is used to notify people of installation, operation, programming, or maintenance information that is important, but not hazard-related.

1.2 General Precautions

Before you use the antenna, make sure that you have read and understood all safety requirements.

	THIS WAY UP Place the boxes/crates on the floor with the arrow pointing up.
	FRAGILE Since the Radome is fragile, handle it with care. Do not apply excessive pressure or shock. This can cause surface cracking or other damage.
	DO NOT STACK Do not stack boxes/crates as there is a risk boxes/crates may fall and be damaged.
	KEEP DRY - Always make sure the antenna is stored on a dry surface in a dry, well-ventilated area. - The antenna is designed to withstand a normal rain shower; however, water resistance cannot be guaranteed if the antenna is submerged.

* **DO NOT SHIP VIA RAIL:** Ensure not to ship any system via rail.

* **DO NOT STORE THE ANTENNA WRAPPED IN A TARP, TENT, VINYL, OR OTHERS:**

To avoid damage to radome paint, do not use a cover on the radome. Using any type of cover may cause paint damage. Intellian radomes are designed to withstand exposure to rain, humidity, and sun/UV rays when assembled according to Intellian instructions, and when the supplied approved hardware and sealants are used. Under no circumstances should an Intellian radome be covered by any protective covering that adheres, bonds, or clings to the surface, whether by self-adhesion or tension.

Chapter 2. Certifications

FCC Part 15 Subpart B Declaration of Conformity (DoC)

We, Intellian Technologies, Inc. located at 18-7, Jinwisandan-ro, Jinwi-myeon (Chungho-ri), Pyeongtaek-si, Gyeonggi-do 17709 Korea declare under our sole responsibility that the product(s) described in the below to which this declaration relates is in conformity with the requirement of the FCC Part 15 Subpart B.

Product Information:

Product Name(s):	Intellian s100N, 109cm Ku-band Maritime TVRO Antenna System Intellian s130N, 125cm Ku-band Maritime TVRO Antenna System
Model Number(s):	T4-107XXX, T4-137XXX

Test Result

Standard	Requirement	Rule Section	Test Report Number	Result
FCC Part 15 Subpart B	Conducted Disturbance	ANSI C63.4:2014	DREKFCC2206-0117	Pass
	Radiated Disturbance	ANSI C63.4:2014	DREKFCC2206-0117	Pass

Supplementary Information:

Testing Organization	DT&C Co., Ltd. 42, Yurim-ro, 154 beon-gil, Cheoin-gu, Yongin-si, Gyeonggi-do 17042, Korea
Technical/Compliance File Held by:	Intellian Technologies, Inc. 18-7, Jinwisandan-ro, Jinwi-myeon, Pyeongtaek-si, Gyeonggi-do 17709 Korea
Place and Date of issue:	Gyeonggi-do, Korea on 17 June, 2022

Authority: Yeonho Kim
/ CTO, R&D

Signature: 

Date: August, 23, 2022

APAC
Headquarter/Innovation Center
18-7, Jinwisandan-ro, Jinwi-myeon
Pyeongtaek-si, Gyeonggi-do
17709 Korea
T +82 31 379 1000

EMEA
Rotterdam Office
Sheffieldstraat 18, 3047AP, Rotterdam,
The Netherlands
T +31 1 0820 8655

AMERICAS
Irvine Office
11 Studebaker
Irvine, CA 92618 U.S.A.
T +1 949 727 4498

RED Declaration of Conformity (DoC)

We, Intellian Technologies, Inc. located at 18-7, Jinwisandan-ro, Jinwi-myeon, Pyeongtaek-si, Gyeonggi-do 17709, Korea declare under our sole responsibility that the product(s) described in the below to which this declaration relates is in conformity with the *essential requirements* and *other relevant requirements* of the Radio Equipment Directive (2014/53/EU).

Product Information:

Product Name(s):	Intellian s100N, 109cm Maritime TVRO Antenna System Intellian s130N, 125cm Maritime TVRO Antenna System
Model Number(s):	T4-107XXX, T4-137XXX

To provide the presumption of conformity in accordance to Annex III(encompassing Annex II) of Directive 2014/53/EU; the following harmonized standards and normative documents are those to which the product's conformance is declared, and by specific reference to the essential requirements of Article 3 of the Directive 2014/53/EU.

2014/53/EU Article	Standard(s) Applied in Full	Result
SAFETY (Art 3.1.a)	EN IEC 62368-1:2020+A11:2020	Pass
EMC (Art. 3.1.b)	EN 301 843-1	Pass
SPECTRUM (Art. 3.2)	EN 303 372-1	Pass

Supplementary Information:

Notified Body Involved: (Testing Organization) - Safety, EMC, SPECTRUM	DT&C Co., Ltd. 42, Yurim-ro, 154 beon-gil, Cheoin-gu, Yongin-si, Gyeonggi-do 17042, Korea
Technical/Compliance File Held by:	Intellian Technologies, Inc. 18-7, Jinwisandan-ro, Jinwi-myeon, Pyeongtaek-di, Gyeonggi-do 17709, Korea
Place and Date of issue:	Gyeonggi-do, Korea on 23 June. 2022

Authority: **Yeonho Kim**
 / CTO, R&D

Signature:  _____

Date: 23th Aug 2022

Intellian Technologies USA, Inc.
US Headquarters
11 Studebaker
Irvine, CA 92618 USA
Tel: +1 949 727 4498

Intellian Technologies, Inc.
EMEA & APAC Headquarters
348-5 Chungho-Ri, Jinwi-Myeon
Pyeongtaek-Si, Gyeonggi-Do, 451-862 Korea
Tel: +82 31 379 1000

Doc Number IT22-DC0207-02

UK-CA Declaration of Conformity

We, Intellian Technologies, Inc. located at 18-7, Jinwisandan-ro, Jinwi-myeon, Pyeongtaek-si, Gyeonggi-do 17709, Korea declare under our sole responsibility that the product(s) described in the below to which this declaration relates is in conformity with the *essential requirements* and *other relevant requirements* according to UK legislation Electrical Equipment (Safety) Regulations 2016 (S.I. 2016/1101).

Product Information:

Product Name(s):	Intellian s100N TVRO Antenna System Intellian s130N TVRO Antenna System
Model Number(s):	T4-107BT3, T4-137BT3

To provide the presumption of conformity in accordance to Annex III(encompassing Annex II) of Directive 2014/53/EU; the following harmonized standards and normative documents are those to which the product's conformance is declared, and by specific reference to the essential requirements of Article 3 of the Directive 2014/53/EU.

2014/53/EU Article	Standard(s) Applied in Full	Result
SAFETY (Art 3.1.a)	EN 62368-1	Pass
EMC (Art. 3.1.b)	EN 301 843-1	Pass
SPECTRUM (Art. 3.2)	EN 301-360 EN 301-459 EN 303-978	Pass

Authority: Yeonho.Kim
/ CTO, R&D

Signature: 

Date: August 1, 2022

Doc Number IT22-DC0721-05

APAC
Headquarter/Innovation Center
18-7, Jinwisandan-ro, Jinwi-myeon
Pyeongtaek-si, Gyeonggi-do
17709 Korea
T +82 31 379 1000

EMEA
Rotterdam Office
Tempelhof 12
3045 PV, Rotterdam
The Netherlands
T +31 1 0820 8655

AMERICAS
Irvine Office
11 Studebaker
Irvine, CA 92618 U.S.A.
T +1 949 727 4498

Chapter 3. Introduction

3.1 Introduction of s100N

Intellian's s100N WorldView™ is a digital marine satellite antenna system specifically designed for reception of worldwide Ku-band satellites, as well as the DIRECTV® services, enabling seamless and uninterrupted satellite TV reception across multiple coverage areas and service providers.

The dual-band 3-axis marine satellite antenna system is capable of receiving two Ka-band satellite signals and one Ku-band signal for DIRECTV® North American programming, making all channels available for viewing simultaneously. The Intellian Ku and Ka-band WorldView™ Trio LNB™ with triple feed horn selects a satellite television provider and connects to a satellite receiver. The WorldView™ Trio LNB can then automatically switch frequency, depending on the region the antenna is operating in.

All Intellian antenna systems are designed, manufactured, and tested to meet industry standards for vibration and shock in nominal weather conditions.

3.2 Features of s100N

Simultaneous Reception of DIRECTV® Ka and Ku-band

The antenna solution incorporates 3 feed horns to simultaneously receive 3 satellites: 2 DIRECTV® 99° and 103° Ka-band satellites and 1 DIRECTV® 101° Ku-band satellite. This allows viewers of satellite programs to watch every DIRECTV® channel without changing satellites.

User Friendly Five Cable Configuration

A user friendly, five cable configuration for global TVRO installers and engineers. There are four independent RF cables that connect the Worldview™ LNB to the multi-switch directly and one power cable that is connected to the ACU.

All New Hardware & Standardized Modular Components

All New hardware and pedestal based on our quality proven VSAT terminals. Modular components are used throughout the new TVRO range, such as dynamic motor brakes with integrated encoders, the Main Control Unit, and the skew assembly. By sharing common modules across Intellian's new TVRO antenna line, the number of spare parts required is reduced.

Hands-Free WorldView™ Trio LNB

The built-in Worldview™ Trio LNB module will automatically switch to the corresponding polarization and local frequency to receive the target satellite signal. This allows users to enjoy any satellite TV service around the world without the need to switch LNBs.

Unlimited Azimuth Range

This Intellian-only solution allows the system to operate in an unlimited azimuth rotating range. It prevents cable problems, such as disconnecting, cutting, and wrapping, that might otherwise occur in the field.

DVB-S2 Digital TV Receptions

Some of the HD TV services have moved to DVB-S2 transmission formats and there will be more in the future. Thanks to Intellian's groundbreaking DVB-S2 digital TV technology, now boaters are able to enjoy their favorite Sat TV entertainment at sea—just like at home.

19-inch Rack-mount Type ACU (Antenna Control Unit)

Intellian s100N ACU offers a pre-programmed global satellites library and provides the power to the antenna. Detailed information and satellite changes are displayed on an OLED display on the ACU front panel.

Multi Switch Module

The Intellian multi-switch module provides simple connections to different types of satellite receivers. The built-in SWM outputs and standard multi-switch outputs support both single wire and standard installations. This reduces the need for additional hardware and reconfiguration of the system when viewing programs on multiple TV screens.

AptusNTV Wireless Connectivity

Intellian's all new integrated M&C platform AptusNTV provides a responsive web user interface. The Installation Wizard function configures the antenna system automatically and minimizes operators' work on system installation and operation. Any kind of wireless device, such as a PC, laptop or smartphone, can connect to the ACU to manage and control the antenna system.

Chapter 4. Planning Installation

The antenna installation requires extreme precaution and safety measures given its size and weight. Failure to follow the correct installation process may lead to injury of the installer and/or cause damage to the system. To maximize the performance of the system, a thorough review of this installation guide is strongly recommended. In addition, you should execute the installation process as it is noted in this manual.

4.1 Selection of Installation Site

The system should be placed in an area onboard the vessel with little to no RF signal blockage. The antenna unit should have direct line-of-sight with the desired satellite without any obstacles in the beam path. Minimum distances between the antenna and other onboard devices must also be considered during installation. Install the antenna in accordance with the following procedures to ensure maximum performance.

4.1.1 Minimize Satellite Blockage

The ideal antenna site should have a clear view of the horizon or satellite with all around clearance. Make sure there are no obstacles within the EL range -15° to $+115^{\circ}$ from the center of the antenna. Any obstacles can prevent the antenna from tracking the satellite signal.




Figure 1: Elevation Limit of Obstacles

4.1.2 Avoid RF Interference

Do not install the antenna near the high power shortwave radar. Most radar transmitters emit RF energy within an elevation range of -15° to $+15^{\circ}$. For this reason, you should position the antenna at least 15 feet (4.6 m) away from the radar.




Figure 2: Potential RF Interference



WARNING

Never place the antenna in the beam path of the radar, regardless of distance. The high power shortwave radar may impair its performance or damage the antenna.

4.2 System Package

4.2.1 Above Deck Unit (ADU)

The ADU includes an antenna pedestal inside a radome assembly unit. The pedestal consists of a satellite antenna main dish with RF components mounted on a stabilized pedestal. The radome protects the antenna pedestal assembly unit from the severe marine environment.



Figure 3: Radome and Pedestal

4.2.2 Antenna Control Unit (ACU)

The ACU provides power to and controls the various settings of the antenna. ACU features include the following:

- OLED display
- USB port to download logs and upgrade firmware (no PC required)
- Wi-Fi access
- AptusNTV web application




Figure 4: Front Panel of ACU



Figure 5: Back Panel of ACU

4.2.3 Multi Switch Module (MSM)

The Intellian Multi-Switch Module provides built-in SWM and standard multi-switch outputs, allowing configuration with DIRECTV® satellite receivers and standard satellite receivers.



Figure 6: Front Panel of MSM




Figure 7: Back Panel of MSM

4.2.4 Packing List

Before beginning installation, make sure you have all the included components.

Item	Q'ty	Size	Description
Above Deck Unit (ADU)	1		Radome and pedestal
Below Deck Unit (BDU)	1	431 mm x 411 mm x 44 mm	Antenna Control Unit (ACU)
Multi-Switch Module (MSM)	1	431 mm x 411 mm x 44 mm	Multi-Switch Module for s-Series
Quick Installation Guide (QIG)	1		Installation guide
Mounting Template	1		Real size drawing of antenna mounting hole pattern
ACU Rack Mount Bracket	2		For installing ACU to 19-inch rack
Flat Head Screw	10	M4 x 12L	
MSM Rack Mount Bracket	2		For Installing MSM to 19-inch rack
Flat Head Screw	10	M4 x 12L	
8-way splitter for SWM	2		SWM (on MSM) to DIRECTV receivers
AC Power Cord (CEEE7/7)	2	1.5 m	Power cord for ACU/MSM (220 V)
Ethernet Cable (RJ45 to RJ45)	1	1 m	To connect ACU to PC
Wi-Fi Dongle	1		For Wi-Fi connection
Hex Bolt-S F	5	M12 x 80L	Bolt kit for antenna-deck (mast) assembly (1 spare set included)
Hex-S Bolt-S F	5	M6 x 40L	Bolt kit for radome assembly (1 spare set included)
Radome Door Key	2		To open the hatch

4.3 System Cables (Customer Supplied)

4.3.1 RF Cables (Customer Supplied)

Due to the signal loss across the length of RF coaxial cable on L-Band, only use 75 Ω coaxial cable types for the RF cables in a standard system installation. The use of different types of cables (50 Ω coaxial types, etc.) can cause problems. If you need RF cables that run longer than the maximum cable length recommended, contact Intellian Technical Support for assistance.

Cable Requirements(Antenna Cable/ RF1 ~ RF4 Cable)

Coaxial Cable Type	Connector	Max. DC Resistance	Attenuation @ 2GHz	Max. Cable Length (≤ 16 dB loss @ 2GHz)
LMR300-75	F (M) to F (M)	0.8 Ω (Antenna cable only)	0.279 dB/m	50 meters
LMR400-75			0.187 dB/m	80 meters



NOTE

- Optimal tightening torque for F type RF connector: 1.0 N-m
- Maximum RF loss at 2 GHz: 16 dB including connectors

4.3.2 Gyrocompass Cable (Customer Supplied)

The following general types of gyrocompass cables are recommended for compatible connection to Intellian antennas used in various environments.

Standard	NMEA 2000	NMEA 0183
Connector Type	Mini-C 5 pin connector	2 pin terminal block connector
Cable Type	5-wire single cable	2-wire cable with one enclosed shield cable
Heading Information	Supports PGN, 127250: Vessel Heading	Supports \$HEHDT, baud rate 4800, format 8N1 as standard

4.4 Unpacking System Package




CAUTION

- The package box on the pallet should be lifted by a forklift.
- Follow the steps in order for easy and safe unpacking.


The pallet should be lifted by a forklift. To unpack the wooden crate, follow the procedure below.

1. Open the side panel with an attached sticker paper (*Wooden Crate Unpack Guide*) by removing a fixing screw (1 ea) and clips (6 ea).


1-1 : 1 ea



1-2 : 6 EA




1-3




2. The ACU box is placed inside of the side panel. Remove the fixing screws (2 ea) from the holding bracket, and then remove the ACU box from the crate.

2




3. Remove the clips (6 ea) on the top panel, and then detach the top panel by carefully pulling it as shown in the figure below.

3-1  : 6 ea




3-2




4. Remove the fixing screws (3 ea side/1 ea back) that secure the side panel (right) and back panel, and then detach the panels.

4  : 4 ea




5. Remove the fixing screws (2 ea) from the MSM box holding bracket (located on the left side panel), and then remove the MSM box from the crate.

5




6. Remove the fixing screws (3 ea) that secure the side panel (left), then detach the panel.

6-1  : 3 ea



6-2



Chapter 5. Installing Above Deck Unit (ADU)

5.1 Antenna Dimensions

Before installing the antenna unit, confirm its height and diameter (see figure below). The mounting surface and overall space occupied by the antenna must be sufficient for the fully constructed radome on top of its base frame. Using a crane during the antenna installation is strongly suggested.

Unit: mm (inches)




Figure 8: Antenna Dimensions



NOTE

Position the antenna with the BOW direction parallel to the center line of the ship.

5.2 Antenna Mounting Hole Pattern

Use the supplied mounting template when drilling mounting holes on the mast. The hole placement for the antenna must match the mounting hole pattern on the template.

**WARNING**

When reusing an existing mast, make sure the location of the holes on the mast correspond to the hole locations and sizes printed on the mounting template.




Figure 9: Antenna Mounting Hole Template

5.3 Designing Mast (Example Only)

The installation mast must be robust enough to prevent flex, vibration, and sway when an external force is exerted on the mast with antenna and radome attached. Refer to the following mast drawings for more details.



NOTE

- This is a general example of designing a mast. The shape of mast may differ depending on the ship's environment.
- Follow the Intellian installation recommendations for safety.

WARNING

- When designing a mast, consider the minimum and maximum thickness of the mast plate marked on the diagram. If the thickness of the mast plate is different from the recommended size (Min. 10.0 mm/ Max. 20.0 mm), choose the bolt size for mounting the antenna on the mast according to the table below.



Mast Plate Thickness	Recommended Bolt Size
10 ~ 28 mm (Recommended)	M12 x 80L (Supplied)
28 ~ 35 mm	M12 x 90L

- To use the supplied bolts (M12 x 80L) for mounting the antenna on a mast, the thickness of the mast plate must be 10 ~ 20 mm. The minimum thickness of the mast plate is 10 mm. If the mast plate is thicker than 20 mm, the supplied antenna mast mounting bolts may be too short to mount the antenna on the mast securely.

Unit: mm (inches)




Figure 10: Recommended Size of Mast

5.4 Routing RF Cable on Mast (Example Only)

The cable must be routed from the antenna and through the ship to end up at the antenna control unit. When pulling the cables in place, avoid sharp bends, kinking, and excessive force. After placement, seal the deck penetration gland and tie the cable securely in place. Cable brackets must be installed on the mast to secure the cable. The gooseneck must be installed on the side of the mast to protect the cable from water.

**WARNING**

Ensure that cable has been run through watertight fittings to prevent water entry into the vessel when installation is completed.

**NOTE**

This is a general example of routing cables on the mast. The routing method may differ depending on the ship's environment.

1. Route the cable from the gooseneck on the deck to the antenna as shown in the figure below.
2. Maintain sufficient cable length (at least 2 m) when routing the cable on the surface of the mast. After connecting the cable to the connector inside the radome, adjust the length and fix the cable on the cable brackets using cable ties.





Figure 11: Routing Cable Through Outside of Mast


5.5 Removing Antenna from Wooden Pallet

Four radome brackets secure the antenna to the pallet. To remove the radome from the pallet and the brackets from the radome, use the following procedure.


1. Remove the hex head wrench bolts (2 ea) from each of the radome brackets (4 ea) using a wrench.



2. Check the condition of the lifting straps, and make sure the shackles (2 ea) are tightened. After checking the shackles, re-wrap them with the existing protection to avoid radome damage.



3. Lift the antenna above the pallet using a crane, and maintain a sufficient space (max. 100 mm) between the bottom of the antenna and the pallet to remove the shipping brackets.






WARNING

- When lifting the antenna using the lifting straps, make sure to remove the securing radome brackets to separate antenna from the pallet.
- Be careful when lifting heavy objects. Incorrect handling of heavy objects may lead to personal injury or significant equipment damage.



4. Remove the radome bracket bolt (1 ea) using a wrench, then detach the radome bracket from the radome.

5. Find the supplied hex head wrench bolts (M6 x 40L), spring washers, and flat washers in the ACU box.
6. Apply Loctite #243 on the bolt, and assemble the bolt and washers to the radome by turning the bolt clockwise using a wrench.
7. Repeat steps 4 through 6 for each remaining radome bracket.



Fully Tighten Radome Bolt.



WARNING

- Fully tighten the radome bolt.
- Use the radome bolt and washers supplied in the ACU box.
- DO NOT reuse the removed bolts and washers.

5.6 Placing Antenna on Mast

The Intellian antenna comes with the lifting straps pre-mounted from the factory.

1. Check the condition of the lifting straps and ensure the shackle is tightened up.
2. Lift and move the antenna above the mast using a crane, then carefully put the antenna down on the mast.




Figure 12: Placing Antenna on Mast



WARNING

The antenna may sway in the wind when suspended by a crane. Be careful when handling the antenna.



NOTE

Position the antenna with the BOW direction parallel to the center line of the ship.

5.7 Mounting Antenna on Mast

1. Bring the M12 x 80L hex bolts (4 ea) for the antenna-mast assembly from the ACU box.
2. Align the mounting holes of the antenna with those of the mast.
3. Apply Loctite #263 to the bolt threads, insert the bolts and washers from under the mast into the built-in nuts on the bottom of the radome (see Figure 14), and then lightly tighten them by hand. Use a crisscross sequence as shown in Figure 13.
4. After installing all 4 bolts, fully tighten the bolts using a torque wrench in the crisscross sequence. Refer to **"12.1 Appendix A. Tightening Torque Specification" on page 103**.
5. Remove the lifting strap from the antenna.




Figure 13: Installing Sequence of Bolts




Figure 14: Installing Bolts for Antenna-Mast Assembly

NOTE



- Make sure the cable from the mast is aligned with the cable entry on the bottom of antenna for stable connection.
- Refer to **"12.1 Appendix A. Tightening Torque Specification" on page 103** for the bolt tightening torque.



WARNING

If a bolt does not fit into the mounting hole when installing the bolt by hand, stop installing and check the bolt size. **DO NOT** tighten the bolts forcefully. Forceful tightening can damage the inner threads of the antenna mounting holes. This type of damage is not covered by the warranty.

5.8 Connecting RF Cable to Antenna

Connect the RF Cable (customer supplied) from the ANTENNA port of the ACU to the RF connector inside the cable entry compartment of the radome. Both sides of the connection cable should be terminated using suitable tools. After the connection, securely fix the cable in place using cable ties.




NOTE

Make sure of the following before installing system cables.

- All cables need to be well clamped and protected from physical damage and exposure to heat and humidity.
- Do not use any acutely bent cable.
- Use watertight glands or swan neck tubes at exposed bulkheads or deck heads where the cable passes through.
- Install recommended size cables. Refer to "**4.3 System Cables (Customer Supplied)**" on page 18 for cable requirements.


1. Loosen the M4 x 15L bolt (1 ea) using a wrench, and then open the cable entry cover.




NOTE

Keep the detached cover in a safe place for later use.


2. Terminate the RF cables with F (M) connectors. Intellian recommends using genuine cable connectors and tools. Refer to the cable termination instructions provided by the connector manufacturers.
3. Connect the RF cables (antenna cable and RF cables) to the connectors as shown in the following figure.



4. Make sure that the cables are firmly fastened to the connectors, and then apply tape over the connectors for waterproofing. Refer to **"12.2 Appendix B. Important notice of waterproofing connector" on page 104.**
5. After completing cable connection, replace the cable entry cover.



6. Tighten the cover in place with the M4 x 15L built-in bolt using a wrench.



Chapter 6. Installing Below Deck Unit

6.1 Selection of BDU Installation Site

The ACU and MSM should be installed below the deck in a location that is dry, cool and ventilated. The front panels of the ACU and MSM should be easily accessible to users.



WARNING

This product is installed where the circuit breaker is connected to the power source.

6.2 ACU Dimensions

Confirm the dimensions of the ACU before installing it.




Figure 15: ACU Dimensions

6.3 MSM Dimensions

Confirm the dimensions of the MSM before installing it.




Figure 16: MSM Dimensions

6.4 Mounting ACU/MSM

Mounting ACU/MSM in a 19" Rack

The ACU/MSM can be installed in a 19" rack using the four rack mount brackets that are included in the ACU and MSM boxes. Attach the rack mount brackets to the sides of the ACU and MSM using the included M4 x 12L flat head screws (16 ea). Connect cables to the back side of the ACU and MSM.



Figure 17: 19-inch Rack Mount ACU (Applies to MSM)



WARNING

Ensure that the cables connected to the ACU and MSM are long enough to prevent damage when they are pulled out from the rack.

6.5 System Configurations

For the proper operation of the satellite communication system, the required components must be connected as shown in the figure. Separate purchase of a ship's gyrocompass may be needed.

6.5.1 Single Antenna System Configuration

The basic system consists of one antenna, one ACU and one MSM. Connect the cables as shown in the configuration below.




Figure 18: Multi-Switch Connection Configuration

6.5.2 Dual Antenna System Configuration (Optional)

The dual system configuration consists of two TVRO antennas, two ACU, one MSM, and one Mediator. The new TVRO Mediator, which is capable of controlling and managing two TVRO antenna systems simultaneously, is sold separately. Connect the cables as shown in the configuration below.




Figure 19: Dual Antenna System with Multi-Switch Connection Configuration



NOTE

The New Dual TVRO Mediator is sold separately.

6.6 BDU Cable Connection

6.6.1 ACU Back Panel Connectors

The following figure shows the ACU back panel connectors.




Figure 20: ACU Back Panel Connectors

6.6.2 MSM Back Panel Connectors

The following figure shows the MSM back panel connectors.





Figure 21: MSM Back Panel Connectors

6.6.3 ACU Connector Pinout Guide

Reference the following connector pinout information for the connection ports of the ACU.


Power Connector



IEC 320 C14 Plug Male

Pin	Signal
1	LIVE
2	GND
3	NEUTRAL


Antenna Connector



RF F Type Female

Conductor	Function
Inner	DATA, POWER
Outer	GND


HEADING (NMEA 0183) Connector



2-Pin Terminal Block

Conductor	Function
-	HEADING GND
+	HEADING IN


NMEA 2000 Input



Mini-C 5-Pin Male


Pin	Signal
1	Shield
2	NETS, (power supply positive, +V)
3	NETC, (power supply common, -V)
4	NET-H (CAN-H)
5	NET-L (CAN-L)

GPS Connector




D-Sub 9-Pin Female

Pin	Signal
1	GND
2	GPS OUTA
3	N/C
4	N/C
5	GPS_IN
6	GPS_OUTB
7	N/C
8	N/C
9	GPS_GND

ETHERNET (LAN) Connectors

RJ-45 Female

Pin	Signal
1	TX-
2	TX+
3	RX-
4	N/C
5	N/C
6	RX+
7	N/C
8	N/C

Wi-Fi Dongle USB Connector


USB A Female

Pin	Signal
1	+5 V
2	DATA-
3	DATA+
4	GND

6.6.4 MSM Connector Pinout Guide

Reference the following connector pinout information for the connection ports of the MSM.


Power Connector



IEC 320 C14 Plug Male

Pin	Signal
1	LIVE
2	GND
3	NEUTRAL

Cable Connector



RF F Type Female

Conductor	Function
Inner	DATA
Outer	GND

6.6.5 Connecting Power to ACU

Connect the power cord from the power supply to the power connector (100-240 VAC) of ACU.



Figure 22: Connecting Power to ACU

6.6.6 Connecting ACU to ADU

Connect an **Antenna Cable (F to F)** (customer supplied) from the ANTENNA (F) port of the ACU to the Antenna RF (F) port of radome (antenna).




Figure 23: ACU to Antenna Cable Connection

6.6.7 Connecting ACU to Ship's Gyrocompass

For satellite tracking, connect a ship gyrocompass to the antenna system through the gyrocompass interface of the ACU. The Intellian ACU supports NMEA 0183 and NMEA 2000 gyrocompass inputs. If the gyrocompass has a different output standard, use a compass converter to supply the required NMEA input. The NMEA 2000 gyrocompass needs to be purchased separately. Refer to "**6.6.3 ACU Connector Pinout Guide**" on page 37 for the pin configuration.





Figure 24: ACU to Ship's Gyrocompass Cable Connection

How to Connect NMEA 0183 Gyrocompass Cable

1. Using a flat head screwdriver, loosen the two screw terminals by rotating them counterclockwise.
2. Strip wires up to 5 mm (0.2"). Do not solder the cables.
3. Insert the conductor and gyro cable wires into the – (negative) and + (positive) terminals, respectively, of the terminal block. Check the polarity to make sure the wires are inserted correctly.



4. Fully tighten the terminal block screws by rotating them clockwise to clamp the wires securely.
5. Insert the terminal block with gyro cables to the **NMEA 0183 (GYRO)** port of the ACU.




Figure 25: NMEA 0183 Gyrocompass Cable Connection

6.6.8 Connecting RF Cables (RF1-4) to the Multi-Switch Module

The Intellian s100N is capable of receiving multiband and multi-polarization satellite TV service around the globe using the Intellian WorldView™ Trio LNB module.

1. Connect the antenna cable from the ACU Antenna connector in the radome to the Antenna connector on the rear of the ACU.
2. Connect RF1 cable to the VL (13 V+0 KHz) port of the Multi-Switch Module.
3. Connect RF2 cable to the HL (18 V+0 KHz) port of the Multi-Switch Module.
4. Connect RF3 cable to the VH (13 V+22 KHz) port of the Multi-Switch Module.
5. Connect RF4 cable to the HH (18 V+22 KHz) port of the Multi-Switch Module.
6. Connect between Multi-Switch Module and receivers using RF cables.
(Up to 26 SWM compatible receivers and up to 8 non-SWM compatible receivers can be connected through the supplied Multi-Switch Module.)




Figure 26: Multi-Switch Module Connection

**NOTE**

Intellian s100N system includes a Multi-Switch Module.

1. When you select a target satellite that is configured in single LNB mode (such as 10750 or 11250), only RF1 (VL) and RF2 (HL) have signals from the Worldview™ Trio LNB module. RF3 and RF4 will have no signal.

RF1	RF2	RF3	RF4
13 V + 0 KHz	18 V + 0 KHz	13 V + 22 KHz	18 V + 22 KHz
VL (Vertical Low)	HL (Horizontal Low)	VH (Vertical High)	HH (Horizontal High)

2. Do Not connect receivers to the RF1~RF4 cables directly.

6.7 ACU to PC Communication Setup

You can establish data communication between the Below Deck Unit/ACU and a PC using a TCP/IP (Ethernet), USB, or Wi-Fi connection and a PC the using one of the following methods.

6.7.1 TCP/IP Connection

Connection through Front Panel Management Port

The network is automatically configured by DHCP with no additional PC IP configuration required.

1. Connect an Ethernet cable from the Management LAN port on the front of the ACU to the LAN port of PC. The network connection is established automatically.
2. Open a web browser (Chrome, Firefox, etc.), and then enter the following IP address to access the Intellian AptusNTV Login page.
 - **IP Address: 192.168.2.1 (Default)**



Figure 27: Front Panel Management LAN Port Connection

6.7.2 USB Connection

Using Right Side USB Port on ACU Front Panel

Connect a USB flash drive to the right side USB port on the front panel of ACU to download logs, backup/restore antenna settings, and upgrade firmware.



NOTE

- The left side USB port is a serial connection and for certified engineer use only.
- AptusNTV access and iARM upgrade are NOT supported through the serial USB connection.



Figure 28: Front Panel USB Port Connection

6.7.3 Wi-Fi Connection

Connection through Wi-Fi Dongle


Intellian provides the Wi-Fi Dongle for Wi-Fi connection to AptusNTV. You can connect a PC to the ACU via Wi-Fi for easy management and control whenever you are on the vessel.

1. Connect an Ethernet cable from the Management LAN port on the front panel of ACU to a LAN port of a PC. The network connection is established automatically.
2. Find the Wi-Fi Dongle in the ACU box, and then insert the Wi-Fi Dongle into the USB port on the back panel of ACU.



Figure 29: Rear Panel Wi-Fi Dongle Connection

3. Open a web browser, and then enter the following IP address to access Intellian AptusNTV page.
 - **IP Address: 192.168.2.1 (Default)**
4. Log in to AptusNTV by typing the User Name and Password. If the system has not been changed from the factory default:
 - **User Name: intellian**
 - **Password: intellian1@1**
5. Select **Setup** on the main menu, and then select the **Wi-Fi** menu.
6. Choose **Enable** for the **Activate** option to edit the configuration.
7. Note the **SSID** (Wi-Fi Access point/network name) information.
8. Choose **Enable** for the **SSID Broadcast** option to show the **SSID** (Wi-Fi Access point/network name) information.
9. Click the **Apply** button to apply the settings to the system.
10. After a reboot, you can connect to the Wi-Fi with any network enabled device.



Chapter 7. Operating Install Wizard

7.1 Turning On System

Make sure the antenna has a clear view of the sky. Press the **POWER** button on the front panel of the Below Deck Unit (ACU), and then wait a few minutes for system startup. Once the antenna finds the satellite, the **TRACKING** indicator light on the ACU display will turn green.

7.2 Accessing AptusNTV

1. Connect an Ethernet cable from the Management LAN port on the front of the ACU to the LAN port of a PC. The network connection is established automatically.
2. Open a web browser (Chrome, Firefox, etc.), and then enter the following IP address to access the Intellian AptusNTV Login page.
 - **IP Address: 192.168.2.1 (Default)**
3. Log in to AptusNTV by entering the User ID and Password.
 - **User ID: intellian (Default)**
 - **Password: intellian1@1 (Default)**




Figure 30: Front Panel Management LAN Port Connection

7.3 Starting Install Wizard

The Install Wizard will give you a guide by going through the steps of setup for the antenna system commissioning. We highly recommend using this wizard to complete the installation and commissioning of the system. You can exit the wizard at any time. You can also skip steps by clicking the > (Next) button. Before you start, make sure the basic devices (antenna, gyrocompass, etc.) are connected to the ACU properly. After accessing the AptusNTV main page, go to the **Install Wizard** on the main menu then follow these steps.

✓ Welcome Page

Welcome message is displayed. Click the > (Next) button to go to the next step.




✓ Step 1: GPS

In this step you check the status of the GPS connected to the antenna system and, if necessary, set the GPS position of the antenna for satellite searching.

- GPS indicator: The colored indicator next to the title shows the GPS status. Make sure the GPS indicator is Blue.
 - Blue: The system received a correct GPS signal.
 - Black: The system has not received any GPS signal. You can enter the GPS value manually to set the GPS position.
- Longitude (°): Set Longitude information (East / West).
- Latitude (°): Set Latitude information (North / South).

Click the **Apply** button to apply the settings to the system and the > (Next) button to go to the next step.



✓ Step 2: Heading

Set the Heading Device to NMEA.

- **Heading Device:** The colored indicator next to the title shows the heading device connection status.
 - Blue: Ship's heading device is connected.
 - Black: Ship's heading device is not connected.
- **Current Device:** Select NMEA from the drop-down list, and then click the Apply button to apply the Heading Device setting to the system. Other heading device options include None, NMEA2000 and Static.
- **Heading (°):** Displays the current heading angle from the ship's gyrocompass. To manually set the heading value, enter the value in the box, then click the Apply button. Note, however, that the value will be updated with the actual heading value immediately.

Click the > (Next) button to go to the next step.



The screenshot displays the 'HEADING' configuration interface. On the left, a sidebar lists navigation items: 'Welcome', 'GPS', 'Heading' (highlighted with a blue arrow), 'Satellite', 'Set Bow Offset', 'Blockages', and 'Install Report'. The main panel is titled 'HEADING' and features a numbered list of steps: 1. 'Heading Device' (marked with a blue bar and an information icon), 2. 'Current Device', and 3. 'Heading(°)'. The 'Current Device' dropdown menu is expanded, showing a list of options: 'None', 'NMEA', 'NMEA2000', and 'Static'. The 'Heading(°)' input field is set to '10'. At the bottom right, there are 'Cancel' and 'Apply' buttons. A red box highlights the 'Current Device' dropdown and its options.

✓ Step 3: Satellite

Display, track, and edit the satellites in the satellite set. For more information about using the Satellite Set, refer to **"9.7.3 Satellite Set" on page 84**.

- **Satellite Set:** Displays the five satellites in the current satellite set. The tracked satellite has a green Active icon. Track another satellite in the set by clicking its gray Inactive icon.
- **Load from Preset:** Displays the Select From Library window with all the satellite sets from the preset library.
- **Set:** In the Select From Library window, click the Set button for the satellite set you want loaded into the Satellite Set window.

Click the > (Next) button to go to the next step.



✓ Step 4: Set Bow Offset

Set the bow offset by tracking a satellite with a strong signal. First make sure you have selected a satellite with a strong signal on the previous step, Satellite Set.

- Search: Click the Start Searching button to detect the bow offset based on the location of the currently tracked satellite.
- Set Bow Offset: Sets the Bow Offset automatically when antenna is tracking a satellite. When the Current Bow Offset displays and the Lock icon turns green, the bow offset is set.

First, select the satellite from the library and update the satellite information. Then, click the Start Searching button.

Make sure the Lock icon turns green, and then click the Save satellite button.

Click > (Next) button to go to the next step.

The screenshot displays a web interface for setting the bow offset. On the left is a sidebar menu with options: Welcome, GPS, Heading, Satellite, **► Set Bow Offset**, Blockages, and Install Report. The main content area is titled '1 SET BOW OFFSET' with navigation arrows. It contains two sections:

Search

Choose a well known satellite in the Satellite library which cover the installation place and Click "Start Searching" button. Bow Offset can be detected when the antenna find and tracking the target satellite with "Lock", then "Save Satellite" button will be activated to save the Bow Offset to the Ant Controller.

Start Searching

2 Set Bow Offset

Please wait until antenna terminal is tracking to satellite. The bow offset will be set up automatically.

Current Bow Offset 0 °

Lock Unlock

Save Satellite

✓ Step 5: Blockage

Up to five antenna blockage zones can be set by entering the relative azimuth and elevation sectors where line of site will be blocked. Setting blockage zones ensures that the programs viewers watch won't be interrupted by keeping the antenna from pointing to those zones.

The **Az. Start** is the relative azimuth angle where the blockage starts, and the **Az. End** is the relative azimuth where the blockage ends (Range: 0 ~ 360). The **El.** is the elevation angle where the blockage is set (Range: 0 ~ 90). The blockage is activated below the set elevation angle.

Click the **Apply** button to apply the settings to the system and the > (Next) button to go to the next step.

Enable	Description	Az. Start~End (°)	El. (°)
☒	Blockage1	185 ~ 205	20
☒	Blockage2	90 ~ 320	20
☐		0 ~ 0	0
☐		0 ~ 0	0
☐		0 ~ 0	0

✓ Step 6: Install Report

The configuration install report is displayed. If you enter a Name, Company, ID, and e-mail, they will be saved with the report.

- Save: Save the results to your PC.
- Export: Download the report file (.json) to the PC or print the report to your system printer.
- View Last Report: Display a window containing the most recently saved report information, including the date and time saved.

This completes the steps of the wizard.

1

INSTALL REPORT

Save

Export

View Last Report

Engineer Information

Name	
Company	
ID	
e-mail	

Antenna Info

Chapter 8. Operating ACU

8.1 Introduction

8.1.1 ACU Front Panel View

The following figure shows the front panel the ACU.




Figure 31: ACU Front Panel View

The following table describes the function of each touch key.


Touch key	Function
Power Button	Powers on/off the System (ACU and ADU).
Move Key	Moves to the desired screen/menu.
Select Key	Selects the desired screen/menu.

The following table describes status indicators on the face of ACU.

LED Display	Color	Description
POWER	Steady Green	The ACU is powered on.
	Off	The ACU is powered off.
TRACKING	Steady Green	The antenna is in tracking mode.
ERROR	Steady Red	The antenna is in an error status.

8.1.2 ACU Display Menu

The following figure shows the ACU display menu.




The following table describes the function of each touch key.


No.	Item	Description
①	Satellite Lock	Displays the satellite lock status.
②	Signal Level	Displays the antenna signal level.
③	Target Satellite	Displays the target satellite longitude (E: East, W: West).
④	GPS Lock Status	Displays the GPS lock status.
⑤	Heading Information	Displays heading information (e.g., gyrocompass).
⑥	Active Target Satellite	Displays the active target satellite from among the current satellite set.
⑦	Antenna Status	Displays the antenna status (TRACKING, SEARCH 1, SEARCH 3, BLOCKING).
⑧	Target Satellite Name	Displays the target satellite name.
⑨	Satellite Position	Displays the satellite position using AZ (azimuth), EL (elevation angle), and SK (skew).

8.2 Startup

With the system is installed and power is applied, the ACU display will show the following sequence.




When the antenna is controlled by Aptus NTV, the ACU displays the control mode status.




✓ **Control Mode Status**

(Displays REBOOT ANTENNA mode or SETUP MODE)



If the antenna does not communicate with ACU, the **COMMUNICATION ERROR** is displayed.




8.3 Satellite Information

Displays the currently registered list of the satellite.




Press
Move Key

✓ **Main Display**




✓ **Satellite Information Display**

Selecting other satellites information




Refer to the Satellite Information display.




No.	Item	Description
①	Satellite List	Displays the registered satellite list (The target satellite name is displayed bright white, while the other four satellites in the set are dimmed.).
②	Satellite Information	Displays the satellite information (Longitude, Frequency, Local, Verify, etc.)

8.4 Interface Information

Displays the GPS/heading type in use and the connection status.




Refer to the Interface Information display.




No.	Item	Description
①	GPS Status/Data	Displays GPS status (displayed white if receiving, dimmed if not) and GPS data (Latitude and Longitude).
②	HEADING Status/Data	Displays heading status and data.
③	Bow Offset	Displays bow offset
④	Heading Device	Displays the heading type in use (NONE, NMEA, STATIC) and BAUD rate. NOTE: Baud rate will be displayed for NMEA Only.

8.5 Antenna Information

Displays the antenna serial number, ACU serial number, firmware version, and ACU software version of the system.



Refer to the Antenna Information.




No.	Item	Description
①	Antenna Serial Number	Displays the Antenna serial number. The serial number is displayed depending on the product.
②	ACU Serial Number	Displays the ACU serial number. The serial number is displayed depending on the product.
③	F/W Version	Displays the Firmware version.
④	ACU Version	Displays the Software version.

8.6 Diagnosis


Executes antenna Diagnosis tests and shows the real-time diagnostic results.




✓ Main Display



✓ Satellite Information Display




✓ Interface Information Display



✓ Antenna Information Display

Product model name and antenna/ACU serial numbers are displayed.



✓ Diagnosis Display

Press the Select key to run the diagnostics.

8.7 USB Function

To use this function, insert a USB flash drive into the right side USB port on the front of the ACU. The USB Function includes four menus (LOG DOWNLOAD, FIRMWARE UPLOAD, BACKUP TO USB, RESTORE FROM USB). Follow the sequence below to access the USB functions. For detailed information about each function, refer to the following subsections.




NOTE

The USB function is activated only when a flash drive is detected in the front panel USB port (right side).




Press
Move Key

✓ Main Display




Press
Move Key

✓ Satellite Information Display



Press
Move Key

✓ Interface Information Display



Press
Move Key


✓ Antenna Information Display

Product model name and antenna/ACU serial numbers are displayed.



Press
Move Key

✓ Diagnosis Display



Press
Select Key

✓ USB Function Display

The USB function is activated only when a flash drive is detected in the front panel USB port (right side).




Press
Move Key

✓ USB Function Menu Display


8.7.1 Log Download

Downloads all data logs to the USB flash drive.



Press
Move Key

✓ USB Function Menu Display




Press
Select Key




Press
Move Key

✓ Log Download Menu Display




✓ Download Log File to USB

Select one of three options: 1 WEEK LOG, 1 MONTH LOG or 3 MONTHS LOG.



✓ Download Process Display

If there is not enough free space on the USB drive, the **NOT ENOUGH SPACE** message is displayed.



NOTE

If you want to go back to the previous screen, select the **BACK** option by pressing the **Select** key.


8.7.2 Firmware Upload

To use the Firmware Upload function, you must use the exact folder structure in the figure below. The function supports FAT32 or older formatted drives. You upgrade the antenna system by copying the FWP file to the /intellian/s100N/firmware folder on a USB flash drive. You also must rename the FWP file to CTR_T4.fwp.




NOTE


The FWP file name must be renamed to CTR_T4.fwp.



If the firmware file in USB is in invalid format, the **INVALID FILE FORMAT** message is displayed.



If any firmware file is not on the USB drive with the correct name and in the correct file structure, the **FILE NOT FOUND** message is displayed.




NOTE


If you want to go back to the previous screen, select the **BACK** option by pressing the **Select** key.

8.7.3 Backup to USB

Backs up the antenna setting files to the USB flash drive.



If there is not enough free space on the USB drive, the **NOT ENOUGH SPACE** message is displayed.




NOTE

If you want to go back to the previous screen, select the **BACK** option by pressing the **Select** key.

8.7.4 Restore From USB

Restores the antenna setting by using the setting files saved on the USB flash drive.



NOTE

If you want to go back to the previous screen, select the **BACK** option by pressing the **Select** key.

Chapter 9. Using AptusNTV

9.1 Introduction

With the embedded **AptusNTV** software, the antenna can be monitored, controlled, and diagnosed remotely from anywhere, anytime through TCP/IP protocol. This saves the time and cost generated by various maintenance activities, such as upgrading firmware, tracking parameter resets, and diagnosing system issues.

9.2 Accessing AptusNTV for ACU


This method is generally recommended.

1. Connect an Ethernet cable from the management LAN port on the front panel of the ACU to the LAN port on a PC.
2. Enter the ACU IP address (**Default: 192.168.2.1**) into the address bar of your web browser. The **AptusNTV** Login page displays.



NOTE

AptusNTV works on Internet Explorer 11 or higher (Windows 7 or higher editions), Firefox, Microsoft Edge and Chrome web browsers.




9.3 Main Page (Page Login)

The Intellian software Aptus provides different user access levels to protect the system for safe operation. The user level determines the accessible range of functions in the software (see the table below).


Log into the ACU by typing in a User ID and Password. The table below contains the factory default values.

User Type	User ID	Password	Access Authority
Admin	sysadmin	sysadmin1@1	All menus for monitoring and setting up the system, as well as account management
Operator	intellian	intellian1@1	All menus for monitoring and setting up the system, but limited menus for account management
User	guest	guest	Dashboard only




NOTE

You must change the default password to a new password for security. When you access the Aptus with a default password, the pop-up window for changing the password will appear. Click the Confirm button. The User Management page displays, where you can change the user password.



9.4 Top Menus

Once you log in, the following information and menus are displayed.



No.	Item	Description
①	Target Satellite	Displays the the target satellite.
②	Lock	Displays the satellite lock status. If the lock icon is lit green, the antenna has locked on the satellite.
③	Signal Level	Displays the current signal level using a yellow bar indicator. The length of the bar increases with signal strength.
④	Antenna Status Info	Displays the antenna status/mode. • Initialize: The antenna system is initializing. • Searching: The antenna is searching for the target satellite. • Tracking: The antenna is tracking the target satellite. • Setup: The antenna is in setup mode. • Diagnostic: The antenna is in dianostic mode. • Idle: The antenna is idle mode. • Communication Error: AptusNTV is unable to communicate with the ACU.
⑤	Main Menu	Select a main menu item (Dashboard, Setup, Tools, Install Wizard). Each main menu item displays side menus on the left of the screen.
⑥	Setup	Enters the setup mode to modify settings.
⑦	Restart	Exits the Setup mode and switches to the normal mode (Searching/Tracking mode).
⑧	Reboot	Powers off and restarts the antenna system. After system initialization, the antenna switches to normal mode (Searching/Tracking mode).
⑨	Save Sat.	Adjusts and saves bow offset automatically. NOTE: Save Sat Button working at Search 3 conditions
⑩	Ant. Info	Obtains current antenna information.
⑪	Account Button	Click the v button to manage the user account The Account, User Management , and System Information menus are for the user management. Click the Logout button to log out of the AptusNTV web page.

9.5 Account Menu

1. Click the User ID  to manage the user account.
2. Select **Account**, **User Management**, **System Information** or **Support** for user management. Select **Logout** to log out of *AptusNTV*.



9.5.1 Account

► Account ①

User Management

System Information

Support

USER

② User Password Change

ID

Old Password

New Password

Apply


③ Session Timeout Change

Session Time min

Apply

No.	Item	Description
①	Account	Updates your password and sets time-outs.
②	User Password Change	You can change your Password. • ID: Displays your user ID. • Old Password: Enter the current password. • New Password: Enter the new password. - 8-32 Characters - A mixture of letters, speacial characters and numbers. - Inclusion of at least one letter, one numner and one special character. Click the Apply button to apply the settings to the system.
③	Session Timeout Change	Enter the value in minutes (60 is default) for setting the session timeout. Click the Apply button to apply the settings to the system.

9.5.2 User Management



Editable User Permission Menu

No.	Item	Description
①	User Management	Sets the a user ID and password information.
②	Add User	Creates new user accounts. To create a new user account, do the following: 1. Click the (+) (Add) button. The User Account window is displayed. 2. Enter the new user ID, Password, and Description (optional). 3. Under Menu Authorization, select the pages to which you want the user to have access. 4. Click the Add button.
③	User Management List	Sets the User information and Permission. • ID: Displays the registered user ID. • Description: Displays the user's description. • ⓘ (Controls): Click the control, and then select one of the following commands to manage the selected user account. - Update User: Displays the User Account window. Change the user ID or choose user permissions by selecting the checkboxes, and then click the Apply button. The user can access only the selected permissions. - Change Password: Displays the Change Password dialog box. Enter the Old and New passwords, and then click the Apply button to set the new password. The next time the user logs in, the new password will be required. - Delete User Account: Displays a confirmation dialog box. Click OK to delete the user account.

9.5.3 System Information

Account

User Management

► System Information ❶

Support

SYSTEM

❷ System Information

Antenna Size	109 cm
Antenna Model Name	s100N
Antenna Model Number	
Antenna S/N	XXXXXXXX
ACU Model Number	
ACU S/N	XXXXXXXX
System Band	
Host controller	v0.18.001
ANT controller	v0.90.902

❸ Antenna Information


Antenna Name

Aptus NTV

CancelApply

No.	Item	Description
❶	System Information	Use this page to display system information and change the antenna name.
❷	System Information (Sub-Menu)	Displays detailed antenna information.
❸	Antenna Information	Enters the Antenna Name. Click the Apply button to set the antenna name.


9.5.4 Support



No.	Item	Description
①	Support	Supports manual downloading, support desk and FAQ list.
②	Manual	Downloads the User Manual and displays Support Desk information. - Download Manual: Click the Download Manual button to view the User Manual. - Support Desk: Click the Support Desk button to open Intellian's contact details for support.
③	FAQ	Provides answers for frequently asked questions about the product.

9.6 Dashboard

The Dashboard menu item provides access to quick monitoring of the antenna status. Once displayed, the Dashboard helps you arrange panels on a single screen, while providing you with a broad view of a variety of information at once. You can customize the dashboard by rearranging the panels to make them more readable and user-friendly.



NOTE

The measured temperature can be different from the actual temperature.

9.6.1 How to Add & Remove Panels (Dashboard Setting)

Adding Panels


1. Click the gear icon on the right side of the page (see figure below). The Dashboard Setting window displays.
2. Check the box of the panel that you wish to add to the dashboard.
3. Click the **Confirm** button to apply the settings to the system.

Once the panel is added, it will be automatically placed at the bottom of the page.




NOTE

You can customize the dashboard by rearranging panels as you wish.



Removing Panels


1. Click the gear icon on the right side of the page (see figure below). The Dashboard Setting window displays.
2. Uncheck the box of the panel that you wish to remove from the dashboard.
3. Click the **Confirm** button to apply the settings to the system.



9.6.2 How to Use Shortcut Settings

Many panels on the dashboard provide a shortcut function. Using the **Shortcut** button on right side of the panel, you can easily access detailed information and manage settings.

1. Click the **Shortcut** button indicated by the red mark to open the setting page.



2. The setting page will appear on an individualized web page. You can check the detailed information and quickly apply the settings that you wish.

9.7 Setup

This menu sets and displays the Ship, Antenna, Satellite, Network, Wi-Fi, and Mediator.

9.7.1 Ship

Ship 1

Antenna

Satellite

Network

Wi-Fi

SHIP

2 GPS ⓘ

Longitude(°)

129.00

EAST

Latitude(°)

33.00

NORTH

Cancel

Apply

3 Heading Device ⓘ

Current Device

NMEA

Baud Rate

4800

Heading(°)

0

Cancel

Apply

4 BOW Offset ⓘ

Current Bow Offset(°)

179

Cancel

Apply

5 Blockage ⓘ

Enable	Description	Az. Start-End (°)	El. (°)
☒	Blockage1	185 ~ 205	20
☐		0 ~ 0	0
☐		0 ~ 0	0
☐		0 ~ 0	0
☐		0 ~ 0	0

Cancel

Apply

No.	Item	Description
①	Ship	Sets the ship information and blockage zones.

79

No.	Item	Description
②	GPS	Sets the GPS position of the vessel for searching for a satellite. Check the GPS status connected to the antenna system. The indicator to the left of the help button shows the GPS status. Make sure the GPS indicator is Blue. GPS Indicator : Blue: the system received a correct GPS input. Black: the system has not received a GPS input. You can enter the GPS value manually to set the GPS position.) • Longitude (°): Set Longitude information (East / West). • Latitude (°): Set Latitude information (North / South). Click the Apply button to apply the settings to the system.
③	Heading Device	Sets the ship's heading device. Choose the device type from the Current Device drop-down list. The indicator to the left of the help button shows the device connection status. Heading Device Indicator Blue: a ship's heading device is connected. Black: a ship's heading device is not connected.) • Current Device: Select the heading device (None, NMEA, NMEA2000 Static).If you select NMEA, you can also set the Baud Rate. • Heading(°): Enter the heading information. Click the Apply button to apply the settings to the system.
④	Bow Offset	For setting the bow offset, you need to select a satellite which is trackable in satellite library information. When the antenna tracks the selected satellite, bow offset will be set up automatically. • Current Bow Offset (°): Enter the Bow Offset Range (0 – 360°). Click the Apply button to apply the settings to the system.
⑤	Blockage	Up to five antenna blockage zones can be set by entering the relative azimuth and elevation sectors where line of site will be blocked. Setting blockage zones ensures that the programs viewers watch won't be interrupted by keeping the antenna from pointing to those zones. The Az. Start is the relative azimuth angle where the blockage starts, and the Az. End is the relative azimuth where the blockage ends (Range: 0 ~ 360). The El. is the elevation angle where the blockage is set (Range: 0 ~ 90). The blockage is activated below the elevation angle. Click the Apply button to apply the settings to the system.

9.7.2 Antenna Setting

Ship
Antenna 1
Satellite
Network
Wi-Fi

ANTENNA

2

Antenna Angle ⓘ

Relative Azimuth 97.51
Absolute Azimuth 97.51 / 281.02 < 5 >
Elevation 44.44 / -22.27 ▾ 5 ▴
LNB Pol Angle 39.50 / 63.43 < 1 >

3

Thresholds Setting ⓘ

Tracking Level 30
Detect Level 70
Cancel Apply

4

Search Parameter ⓘ

Search Step(°) 0.5
Search1 Azimuth(°) 400
Search1 Elevation(°) 8
Search3 Azimuth(°) 3
Search3 Elevation(°) 4
Cancel Apply

5

Conical Range ⓘ

Azimuth 100
Elevation 100
Cancel Apply

6

Conical Range Check

Switch Activation On Off

7

EI Adjust ⓘ

EI Adjust(°) 0
Cancel Apply

8

Tilt Sensor Bias ⓘ

Ready
EL 0.00 ▾ 1 ▴
CL 0.00 ▾ 1 ▴

9

Rate Sensor Bias ⓘ

Az -34
EI 38
CI 81
Cancel Set Rate Sensor Bias
Rate Sensor Calibration Save Sensor Bias



10

Set Idle Mode

No.	Item	Description
①	Antenna	Sets current antenna position and search parameters. These parameters should only be changed by an authorized service technician. Improper setting of these parameters will render your system inoperable.
②	Antenna Angle	The system must be in Setup Mode to modify these settings. Sets current antenna position. You can move the antenna's azimuth and elevation position by using the arrows or inputting a value to find the desired satellite manually. • Relative Azimuth: Displays the antenna's relative azimuth angle. • Absolute Azimuth: Adjusts the antenna's absolute azimuth angle. • Elevation: Adjusts the elevation angle. • LNB Pol Angle: Adjusts the LNB Pol angle. Click the Apply button to apply the settings to the system.
③	Thresholds Setting	Sets current detect level threshold and tracking level threshold. • Tracking Level: Enter the current tracking level threshold. • Detect Level: Enter the current detect level threshold. Click the Apply button to apply the settings to the system.
④	Search Parameter	Sets the time-out, search step and search range. • Search Step(°): Set increment step size. • Search1/3: Set Search 1 and 3 search range. Search is conducted in a two-axis pattern consisting of alternate movements in azimuth and elevation to form an expanding square. Click the Apply button to apply the settings to the system.
⑤	Conical Range	The relative force of the motors controlling azimuth and elevation. Sets the conical range while the antenna is in tracking mode. Click the Apply button to apply the settings to the system.
⑥	Conical Range Check	The system must be in Setup Mode to modify these settings. Monitors the Azimuth and the elevation value when the conical range is modified. • Switch Activation: Choose whether to use the switch activation function (On / Off).
⑦	EL Adjust	Sets Elevation Offset angle. You can adjust Elevation Offset by inputting a value to find the desired satellite manually. Click the Apply button to apply the settings to the system.
⑧	Tilt Sensor Bias	NOTE: The rate values of the azimuth, elevation, and cross-level axes were calibrated to the optimal condition at the factory prior to shipment. If the additional rate adjustment is required, make sure that the antenna is placed on a rigid and flat platform. During the calibration process, the antenna must avoid any motion as it can affect the antenna's performance. Maintain the elevation and the cross-level axes to keep the pedestal parallel to the horizon. • Ready: Click the Ready button to bring the elevation and cross-level to 0. • EL/CL: Select EL/CL and click the Up and Down arrow keys to adjust the elevation and cross-level.

No.	Item	Description
⑨	Rate Sensor Bias	NOTE: The rate values of the azimuth, elevation, and cross-level axes were calibrated to the optimal condition at the factory prior to shipment. If the additional rate adjustment is required, make sure that the antenna is placed on a rigid and flat platform. During the calibration process, the antenna must avoid any motion as it can affect the antenna's performance. Calibrates DC voltage output from the three rate sensors used to sense antenna motion in azimuth, elevation and cross-level axes. These are used to sense antenna motion that corresponds to the ship's motion (roll, pitch, and yaw) for stabilizing the pedestal. The DC voltage output from each of the rate sensors may vary by an amount which is directly proportional to the direction and rate of motion induced on it. • Rate Sensor Calibration: Click the Rate Sensor Calibration button to calibrate the rate sensor automatically. The indicator left of the help button shows the rate sensor calibration status. - Black: The calibration is ready to start. - Blue: The calibration is completed. - Red: The calibration is failed. - Green: The calibration is in process. • Save Sensor Bias: Click the Save Sensor Bias button to save the calibrated value of the rate sensor to the system.
⑩	Set Idle Mode	Sets the motor to idle mode to check the antenna's balance. • Set Idle Mode: The system must be in Setup Mode to modify this setting. Releases the elevation and cross-level motor. • Reboot: Reboots the system.

9.7.3 Satellite Set



No.	Item	Description
①	Satellite	Sets the current tracking satellite from the library and edits the satellite information.
②	Satellite Set	Sets the current tracking satellite from the library and edits the satellite information. Selects active satellite from the set. The Inactive icon will change to a green Active icon. You can check the satellite information of the activate satellie by clicking . You can then edit satellite information or change the activate satellite from the library. To change the satellite set, click the Load From Preset button.

9.7.4 Network


The screenshot displays the 'NETWORK' configuration page. On the left sidebar, 'Network' is highlighted with a circled '1'. The main content area is divided into two sections. The first section, 'Management Port Configuration' (2), contains input fields for IP Address (192.168.2.1), Subnet Mask (255.255.255.0), Lease Start Address (192.168.2.101), Lease End Address (192.168.2.200), and Lease Time (604800), followed by 'Cancel' and 'Apply' buttons. The second section, 'Ethernet Port Configuration' (3), contains input fields for IP Address (10.1.124.47), Subnet Mask (255.255.254.0), and Gateway (10.1.124.254), also followed by 'Cancel' and 'Apply' buttons.

No.	Item	Description
①	Network	Sets the ACU's internal IP address and ports.
②	Management Port Configuration	Sets the Management Port's network configuration. The Management Port is located on the ACU front panel. • IP Address: Set the network IP address (Factory default: 192.168.2.1). • Subnet Mask: Set the subnet mask (Factory default: 255.255.255.0). • Lease Start Address: Set the lease IP address start range. DHCP will only assign IP addresses within the start and end range. • Lease End Address: Set the lease IP address end range. • Lease Time: Set the lease IP address update time. This is the amount of time in seconds (default 604800 seconds or 7 days) that an IP address is reserved for a network device. Click the Apply button to apply the settings to the system.
③	Ethernet Port Configuration	Sets the network configuration of the Ethernet port on the ACU back panel. For service only. • IP Address: Set the network IP address (Factory default: 192.168.0.223). • Subnet Mask: Set the subnet mask (Factory default: 255.255.255.0). • Gateway: Set the gateway IP address (Factory default: 192.168.0.223). Click the Apply button to apply the settings to the system.

9.7.5 Wi-Fi

No.	Item	Description
①	Wi-Fi	Sets up the Wi-Fi connection of ACU.
②	Wi-Fi Config	Displays Wi-Fi configuration. Connect the Wi-Fi dongle to the USB port on the ACU rear panel. When Wi-Fi is enabled, the indicator to the left of the help icon is either blue (Wi-Fi broadcasting) or black (Wi-Fi not broadcasting). • Activate: Sets the Wi-Fi function by toggling the activation button (Enabled/Disable). • SSID: The SSID is the name that allows devices to identify and connect to the wireless network. The SSID is case-sensitive and must not exceed 32 alphanumeric characters, and it can be any keyboard character. The SSID is the same for all devices that connect to your wireless network. • SSID Broadcast: Sets the SSID broadcast function by toggling the activation button (Enabled/Disable). • Channel: Selects an appropriate channel from the list provided to correspond with your network settings. All devices that connect to your wireless network will use the same channel automatically. Try to avoid conflicts with other wireless networks by choosing a channel where the upper and lower three channels are not in use. • Mode: Set the security mode type (Open/Secret). • Passphrase: Enter the password required to connect to Wi-Fi. Click the Apply button to apply the settings to the system.

9.7.6 Mediator (Optional)



No.	Item	Description
①	Mediator	Sets up the dual antenna mediation function.
②	Mediation	Sets up the mediation function for use in a dual antenna system with a dual TVRO mediator. • Use: Set up the mediation function by selecting Enable or Disable. Click the Apply button to apply the settings to the system.



NOTE

The Dual TVRO Mediator is sold separately. Refer to the Dual TVRO Mediator User Manual for installation and operation.

9.8 System Tools

This menu sets and displays the ACU Upgrade, F/W Upgrade, Library, Satellite Preset, Backup & Restore, Reset, Logs and Diagnostic system tools.

9.8.1 ACU Upgrade

No.	Item	Description
①	ACU Upgrade	Upgrades antenna software.
②	File Upload	Browse and select the package upgrade file to upload, and then click the Upload button. The update may take a few minutes to complete. The upload time may vary due to a variety of factors, such as network speed. Uploading an incorrect file may cause serious damage to your antenna and ACU. Refer to the following " Antenna Software Upgrade Procedure " page for more details.
③	System Partition	The ACU has three storage partitions the Sys0, the Sys1 and the Factory Default. Selects the desired storage partitions and click the Activate button. The currently active partition is unavailable for selection. • Sys0: Displays the Sys0 host controller software version. • Sys1: Displays the Sys1 host controller software version. • Factory Default: Displays the Factory Default host controller software version. • Current Partition: Displays the activated storage partition name (Sys0, Sys1 or Factory Default).

Antenna Software Upgrade Procedure:

1. Click the **Browse** button and, in the Windows Open dialog box, select the upgrade package file to upload.
2. Click the **Upload** button to transfer the firmware package file (*.bin) to the Antenna module. The antenna Software versions are displayed in a new window.




File Upload

1 Browse SSERIES_v0.23.01.bin 2 Upload

**NOTE**

If you select the box "Ignore warnings during installation and force the installation to continue", warning messages do not appear during the upgrade.

3. Check the current version installed and the new version available, and then click the **Update** button.




Aptus NTV

Name	Current	New
ACU	0.21.2	0.23.0

Cancel Update

During the upgrade process, the window will display progress status.




Aptus NTV

Name	Progress	Status
ACU	100%	Success

Done

If the software is successfully upgraded, Success is displayed in the Status column.



Aptus NTV

Name	Progress	Status
ACU	100%	Success

Done

4. Click the **Done** button to close the update window.

9.8.2 Firmware Upgrade

The screenshot shows a web interface for firmware upgrade. On the left is a sidebar menu with options: ACU Upgrade, F/W Upgrade (selected and marked with a circled 1), Library, Satellite Preset, Backup & Restore, Reset, Logs, and Diagnostic. The main content area is titled 'F/W UPGRADE' with a circled 1. It contains three sections: 2. File Upload, which has a 'Browse' button, a text input field, and an 'Upload' button; and 3. Rollback (marked with a circled 1), which displays a table of firmware versions and 'Restore' buttons.

F/W UPGRADE		
2 File Upload		
Browse		Upload
3 Rollback		
New	v0.90.002	Restore
Old	v0.90.002	Restore
Factory	v0.90.002	Restore

No.	Item	Description
①	F/W Upgrade	Upgrades the firmware of antenna.
②	File Upload	Browse and select the firmware file to upload, and then click the Upload button. The upload may take a few minutes to complete. The upload time may vary due to a variety of factors, such as your network speed. Uploading an incorrect firmware file may cause serious damage to your antenna and ACU. Refer to the following " Antenna Firmware Upgrade Procedure " page for more details.
③	Roll Back	Displays the new, previous/latest, and factory default firmware package versions and allows you to rollback to them. • New: Restores to the latest firmware version. • Old: Restores to the previous firmware version. • Factory: Restores to factory default firmware version.

Antenna Firmware Upgrade Procedure:

1. Click the **Browse** button and, in the Windows Open dialog box, select the upgrade package file to upload.
2. Click on the **Upload** button to transfer the Firmware file (*.fwp) to the Antenna module. The antenna Software versions are displayed in a new window.

File Upload

1 Browse SSERIES_v0.91.001.fwp 2 Upload

**NOTE**

If you select the box "Ignore warnings during installation and force the installation to continue", warning messages do not appear during the upgrade.

3. Check the current version installed and the new version available, and then click the **Update** button.

Aptus NTV

Name	Current	New
F/W	0.90.011	0.91.001

Cancel Update

During the upgrade process, the window will display progress and status.

Aptus NTV

Name	Progress	Status
F/W	100%	Success

Done

If the software is successfully upgraded, Success will be displayed in the Status column.

Aptus NTV

Name	Progress	Status
F/W	100%	Success

Done

4. Click the **Done** button to close the upgrade window.

9.8.3 Library

LIBRARY

1 Library

ACU Upgrade
F/W Upgrade
Library
Satellite Preset
Backup & Restore
Reset
Logs
Diagnostic

2 Library File

Select Library file to upload

Browse Upload

Download Library File

Download

3 Satellite List

Filter: All

Name	Longitude	Band	LNB Local	Skew Offset	Polarity
DTV_101	101.00 (W)	Ku	11,250	0	LHCP
IS30_DLA	95.00 (W)	Ku	10,500	0	LHCP
DISH_62	61.50 (W)	Ku	11,250	0	RHCP
DISH_72	72.70 (W)	Ku	11,250	0	RHCP
DISH_77	77.00 (W)	Ku	11,250	0	RHCP

Satellite Library

Satellite Information

Satellite Name: ex.) Korea_5

Longitude(°): 0 EAST

Polarity: Linear

Band: VL

Universal: ☒ Disable ☐ Enable

Local Frequency(MHz): 9750

Skew Offset(°): 0

Inclined Search: ☒ OFF ☐ ON

Inclined Angle: 0

Primary Information

Verify Type: DVB Lock

NID: 0x

Frequency(MHz): 0

Cancel Add

No.	Item	Description
①	Library	Displays and edits the satellite library information.
②	Library File	Upload or download the satellite library. - Select a library file to upload: Click Browse button to select the library file to upload, and then click the Upload button. The update may take a few minutes to complete. - Download a library file : Library data (.isl) can be downloaded. Click the Download button.
③	Satellite List	Displays the satellite list and information. - Filter: Select the filter option (All, 160E~73E, 73E~0E, 0W~61W, 61W~160W) from the drop-down list. - Edit() button: To edit the registered satellite , click the Edit () button. The Satellite Library pop-up window is opened. You can edit the following details. - Satellite Information: Sets the current tracking satellite settings. - Satellite Name: Enters the satellite name. - Longitude(°): Enters the satellite orbit position. - Polarity: Selects the polarity from the drop-down list. - Band: Selects the band from the drop-down list. - Local Frequency(MHz): Selects the local frequency from the drop-down list. - Skew Offset(°): Enters the skew offset. - Inclined Search: Sets the inclined search. - Inclined Angle: Enters the inclined angle value. - Primary Information: Sets primary tracking information. - Verify Type: Select verify type (AGC Only, DVB Lock, DVB Decode or DSS Decode) from the drop-down list. - NID: Enters the network ID for the frequency. - Frequency(MHz): Enters the tracking frequency of the satellite. Click the Apply button to apply the settings to the system.

9.8.4 Satellite Preset


No.	Item	Description
①	Satellite Preset	Displays and Sets the satellite preset option.
②	Satellite Preset list	Selects a registered satellite preset from the drop-down list. You can change a preset list name. Click Change Preset Name and change it.
③	Satellite Set	Creates the satellite preset from the library. Click the Add Set button. - name: Enters a preset list name. - Satellite List: Adds a satellite from the library. Click the  button and select the satellite. Click the Create button to register the preset list.
④	Satellite	Displays current preset satellites. You can edit satellite information or prest list. - Edit Satellite: Edits detailed satellite information. - Select from Library: Edits the current preset list by selecting a new satellite from the library. - Delete Preset: Delete current preset list. - Change Preset Name: Changes the name of the current preset list.

9.8.5 Backup & Restore

The screenshot displays the 'Backup & Restore' configuration page. On the left, a sidebar menu lists various system functions, with 'Backup & Restore' selected and marked with a circled '1'. The main panel is divided into two primary sections. The first section, 'ACU Backup & Restore' (marked with a circled '2'), includes a 'Backup' button and an 'ACU Restore' area featuring a 'Browse' button to select a file and a 'Restore' button to execute the restoration. The second section, 'Antenna Backup & Restore' (marked with a circled '3'), similarly contains an 'Antenna Backup' button and an 'Antenna Restore' area with 'Browse' and 'Restore' buttons for managing antenna settings.

No.	Item	Description
①	Backup and Restore	Backs up user configuration files to PC and Restores the ACU/Antenna settings.
②	ACU Backup & Restore	Backs up or restores ACU setting. - ACU Backup: Stores user Host configuration files on your PC. Click the Backup button to store the ACU configuration on your PC. - ACU Restore: Restores the ACU settings using the setting files saved on your PC. Click the Browse button to select the saved backup file from your PC, and then click Restore button to restore the ACU setting.
③	Antenna Backup & Restore	Backs up or restores antenna settings. - Antenna Backup: Stores user antenna configuration files on your PC. Click the Backup button to store the antenna configuration on your PC. - Antenna Restore: Restores the antenna setting by using the setting files saved on your PC. Click the Browse button to select the saved backup file from your PC, and then click the Restore button to restore the backup antenna settings to the system.

9.8.6 Reset



No.	Item	Description
①	Reset	Resets the antenna system, settings and logs.
②	Reboot	Click the Reboot button to reboot the antenna system. The user configuration is not reinitialized.
③	Factory Reset	Click the Factory Reset button to initialize the antenna system. The user configuration is initialized.
④	Reset Logs	Click the Logs Reset button to initialize all logs. the antenna system and logs are cleared.

9.8.7 Logs

ACU Upgrade
F/W Upgrade
Library
Satellite Preset
Backup & Restore
Reset
Logs ①
Diagnostic

LOGS ⓘ

2 Log Download

From 10/7/2022 To 10/7/2022

☒ Include Antenna Backup

Download Log File

No.	Item	Description
①	Logs	Downloads the antenna log data.
②	Log Download	Allows you to download ACU and antenna log files for a specified date range. - From/To: Sets the date range for which you want to download files. Any log data up to a month old can be downloaded. - Include Antenna Backup: Downloads antenna log files along with the ACU log files. If you do not select this option, only ACU log files will be downloaded. - Download Log File: Downloads the specified log files in a compressed archive file (.tgz).

9.8.8 Diagnostic

The screenshot shows the 'DIAGNOSTIC' interface. On the left, a sidebar menu lists various system functions, with 'Diagnostic' selected and marked with a circled '1'. The main panel, marked with a circled '2', is titled 'DIAGNOSTIC' and contains a table of tests. Each test has a checkbox in the first column, followed by the test name, and then 'Status' and 'Result' columns. All checkboxes are checked, and all status and result values are dashes. A 'Start' button is located at the bottom right of the table.


☒	Test	Status	Result
☒	Ant. Communication	-	
☒	Az Motor	-	
☒	EI Motor	-	
☒	CI Motor	-	
☒	Skew	-	
☒	Sensor	-	
☒	LNB	-	
☒	Antenna Power	-	
☒	ACU Power	-	

Start

No.	Item	Description
①	Diagnostic	Executes antenna Diagnostic test to check the antenna status.
②	Diagnostic	Select the checkbox for each test that you want to run on the system. You can select all the tests quickly by selecting the top checkbox. Click the Start button to run the test.

9.9 Install Wizard

Refer to the "7.3 Starting Install Wizard" on page 49 for more details.



Chapter 10. Specification

10.1 Technical Specification

Above Deck Unit (ADU: Antenna)			
Antenna Radome Height		1458 mm (57.4")	
Antenna Radome Diameter		Ø1379 mm (54.3")	
Antenna Reflector Diameter		Ø1090 mm (41.9")	
Antenna Unit Weight (with Radome)		105 kg (231.4 lbs)	
Platform		3-axis: Azimuth, Elevation, Cross-level	
Positioning		3-axis Velocity Mode Servo Control: Azimuth, Elevation, Cross-Level	
Pedestal Motion Range	Azimuth Range		Unlimited
	Elevation Range		-15° to +115°
	Cross-level Range		Up to ±42°
Stabilization Accuracy		0.2° max in presence of specified ship motions	
Ship Motions	Roll		±25° at 6 second
	Pitch		±15° at 6 second
	Yaw		±8° at 6 second
	Turning Rate		Up to 10°/sec ²
AZ/EL/CL Motor		Brushless DC motor with Encoder	
Sensor		3 Gyro-Rate Sensors & 1 Tilt Sensor (Fixed Sensor)	
Rx	Ku-Band	Frequency	10.7 GHz ~ 12.75 GHz
		Gain	Min. 41.0 dBi @ 12.5 GHz (excl/Radome)
	Ka-Band	Frequency	18.3 GHz ~ 20.2 GHz
		Gain	> 42.0 dBi @ 18.55 GHz (excl/ Radome) > 43.0 dBi @ 19.95 GHz (excl/ Radome)
	Ka-Band	99.2°	1.8°±0.3°
		102.8°	2.2°±0.3°
Polarization	Ku-Band		Linear & Circular Polarization
	Ka-Band		Circular Polarization
Feed Assembly		Cassegrain type	
Minimum EIRP	Ku-Band		42.0 dBW
	Ka-Band		45.0 dBW
LNB		New 5-ports WLNB	
ACU to ADU Cable (Antenna Cable)		Single 75 Ω coax RF cable connected from ACU to ADU for FSK and DC Power	
Input Power		ACU provide 48 VDC (Max. 500 W) over the Antenna Cable	

Below Deck Unit (ACU)	
ACU Size	431 mm x 350 mm x 44.3 mm (17.0" x 13.8" x 1.7")
ACU Weight	4.8 kg (10.6 lbs)
Display	256 x 64 Graphic OLED
Key	Two Push Keys
LED Indicator	Three LEDs for Power, Tracking and Error
USB Port	Two Ports at front panel and One for Wi-Fi dongle at rear panel
Ship's Gyrocompass Interface	NMEA 2000, NMEA 0183
GPS Interface	GPS IN/OUT
Ethernet port	One Management Port at front panel and One External Port at rear panel
Input power	100-240 VAC, 50-60 Hz, 3.3 A
Output Power	48 VDC for ADU (Antenna)
Multi Switch Module (MSM)	
MSM Size	431 mm x 360 mm x 44.3 mm (17.0" x 14.2" x 1.7")
MSM Weight	5.3 kg (11.7 lbs)
LED Indicator	One LED for Power
Connector	Antenna Interface: F-Type (RF1~RF4) SWM compatible STB Interface: F-Type (SWM1, SWM2) Universal STB Interface: F-Type (OUT1~8)
Input Power	100-240 VAC, 50-60 Hz, 1.5 A

10.2 Environmental Specification

Test	Intellian Standard	
Temperature (ADU)	Operational	IEC-60945 (-25° C to +55° C, Power On)
	Survival	IEC-60945 (-40° C to +80° C, Powered On and a non-functional state)
	Storage	IEC-60945 (-40° C to +85° C, Power off)
Temperature (ACU)	Operational	IEC-60945 (-15° C to +55° C)
	Survival	IEC-60945 (-25° C to +70° C)
	Storage	IEC-60945 (-40° C to +85° C)
Wind	56 m/sec (125 mph)	
Humidity	IEC-60068-2-30 Upper Test Temp: +40° C (-3), Humidity 98% Lower Test Temp.: +15° C (+3), Humidity 71% ~ 78%	
Vibration	Operational	IEC-60945, Method: IEC60068-2-6 Freq.: 5 to 13.2 Hz/1mm 13.2 to 100 Hz/0.7g Sweep rate 0.5 Oct/min
	Survival	IEC-60721-3-6 Class 6M3, Method: IEC 60068-2-6 Freq.: 4 to 18 Hz/1.5mm 18 to 200 Hz/2g Sweep rate 1 Oct/min
Shock	Operational	IEC-60721-2-27 2 g/20 ms, 4 g/20 ms, 10 g/11 ms, 20 g/7 ms ±X, ±Y, ±Z each Axis 3 Times
	Survival	IEC-60721-3-6 Class 6M3 10 g/11 ms, 30 g/6 ms, 50 g/3 ms ±X, ±Y, ±Z each Axis 3 Times
	Bump	IEC-60721-3-6 Class 6M3 25 g/6 ms ±X, ±Y, ±Z each Axis 100 Times
Salt Mist	Saline solution : 5 ±1 % NaCl Storage period: 7 Days (IEC-60945)	
Waterproofing	IPX6 (IEC-60529)	
Solar	IEC 60068-2-5	

Chapter 11. Warranty

Warranty Policy

Intellian systems are warranted against defects in parts and workmanship, these warranties cover THREE (3) YEAR of parts and TWO (2) YEAR of factory repair labor to return the system to its original operational specification.

Warranty periods commence from the date of shipment from Intellian facility or date of installation, whichever is sooner. The warranty provides a maximum of 6 months additional coverage if submission of authorized form that describes installation occurs within 6 months from the shipment date.

Intellian Technologies warranty does not apply to product that has been damaged and subjected to accident, abuse, misuse, non-authorized modification, incorrect and/or non-authorized service, or to a product on which the serial number has been altered, mutilated or removed. Intellian Technologies, will (at its sole discretion) repair or replace during the warranty period any product which is proven to be defective in materials or workmanship, in accordance with the relevant product warranty policy. All products returned to Intellian Technologies, during the warranty period must be accompanied by a Service Case reference number issued by the dealer/distributor from Intellian Technologies, and (where applicable) a copy of the purchase receipt as a proof of purchase date, prior to shipment. Alternatively, you may bring the product to an authorized Intellian Technologies, dealer/distributor for repair.

Chapter 12. Appendix

12.1 Appendix A. Tightening Torque Specification

This table shows the recommended values of tightening torques.

Bolt Size	Tightening Torque (N-m)
M2	0.5
M2.5	1
M3	1.5
M4	3
M5	6
M6	12
M8	27
M10	50
M12	85
M14	130
M16	200

12.2 Appendix B. Important notice of waterproofing connector

12.2.1 Introduction

During antenna installation, it is important to ensure that once the cable is connected to the antenna, proper waterproofing of the connector must be done with a self-amalgamating tape.

If you need any assistance, please contact Intellian Technical Support (support@intelliantech.com).

12.2.2 Outline of taping

Self-amalgamating tape comes with a protective, plastic peel-away layer that allows the tape to be rolled and shipped. To waterproof a connector, you need to begin by peeling away a portion of this protective plastic layer and then start wrapping the tape around it.



12.2.3 Procedure

1. Connect the cable to the connector to be fully secured.




CAUTION

- DO NOT over-tighten the connector, nuts, or screws when mounting the antenna to prevent any damage.
- DO NOT leave any cables loose and non-fixed, especially for those installed outside of the antenna.

2. Apply tape over the connector.

It is important to wrap the cable onto itself and the best practice is to wrap the tape over itself by 50%, meaning that once you wrap your first layer your second layer should overlap over half of the first layer, and so on. This ensures that you get a strong bond between the different layers of tape that properly adhere to one another.



3. Ensure that the entire RF connector is taped up as shown in the picture right.



**WARNING**

- Note that you cannot use ordinary electrical tape to waterproof the RF connector. Only self-amalgamating tape is able to waterproof the connector properly.
- Failure to do so will result in rust and corrosion to the cable and its connector and this might end up damaging the antenna.