


How to operate the main menu



How to switch the operation mode


NU/CU ENT
NU: North up
CU: Course up

Shifts display or cursor.


Goes back one layer in multi-layer menu.

Select the menu item.
Goes forward to one layer in multi-layer menu.

How to adjust the brilliance of the display and panel




How to open the list




How to open the context menu

For example, context menu for a mark.



Select a mark with the cursorpad.

How to turn the power on/off






- Acknowledges an unacknowledged alert.
- Deletes all setting values on the setting window.
- Deletes registered data at the cursor-selected position.




- Selects and confirms the menu item.
- Enters a numeric character.



CURSOR ON/OFF 0 : Turn the cursor on/off.








Cursor on: Large
(Size selectable from menu.)



Cursor on: Small
(Size selectable from menu.)



DISPLAY 1 : Select the display mode.



ROUTE 2 : Create a new route.



Long press



Repeat these steps to complete the route.



GO TO 3 : Set a destination.



Select the location for a destination.



MOB 4 : Set MOB as destination.



Select [1 Yes].

PLOT ON/OFF 6 : Plot and record ship's track.



The pop-up message "Resuming Track Plot" appears.

To stop plotting.



The pop-up message "Stopping Track Plot" appears.

ZOOM IN 7 **ZOOM OUT 9** : Zoom in/out the display.



MARK EVENT 5 : Put a mark.

With cursor on



Select the location for a mark.

With cursor off



The mark is put at own ship's position.

CENTER 8 : Center the cursor position or own ship's position.

With cursor on

Center the cursor position.

With cursor off

Center own ship's position.

